

In this section we show you how you can care for your skis/boards to a professional standard and get them ready for snow. It's almost like looking over the shoulder of a ski technician.

1) Spray



Simply spray on Nano Tec HF2 universal or cold and leave to dry.

2) Polish



When dry, polish the base thoroughly using Dual Pad or Thermo Pad.

1) Apply



Apply Express or Paste wax evenly using the sponge applicator and leave to dry.

2) Polish



When dry, polish the base thoroughly using Dual Pad or Thermo