

JetStream is a 100% perfluorocarbon wax and is used as a high-tech finish. This totally synthetic wax takes water and dirt resistance to the limits of what is possible. Abrasion is reduced to a minimum. Because of its absolutely top glide performance, this is a product which belongs to the standard equipment of every ski service technician.

## 1) Sprinkle on



Sprinkle JetStream Powder evenly onto the base.

## 2a) Cork



Use the wax cork to cork the powder (the more frictional heat that is produced, the better JetStream adheres to the base). Can also be worked in using the Rotary Cork Roller (work with a high number of revolutions but without applying pressure).

or...

## 2b) Iron in



Move the iron slowly but steadily over the base (150°C).

## 3) Scrape off



Gently scrape off excess material with the Plexi stripping blade.

#### **4) Brush**



Lightly brush out the powder with Base Brush Horsehair.

#### **5) Polish**



Polish