

SportLine GripSpray

1) Buff any chipped areas



Thoroughly buff any chipped areas using sandpaper and remove dust using Base Tex.

2) Apply GripSpray and cork



Apply a thin layer of GripSpray to chipped areas. Spray on one half first, followed by the other half. Then apply Plasto Kork. **Important:** Keep GripSpray as upright as possible when spraying!



Leave to dry. Leave GripSpray to dry on the base for at least 5 minutes. For best results, leave GripSpray to dry overnight.

If the effect of the GripSpray starts to diminish, apply another layer (universal or x-warm).

Tip: even with GripSpray, a basic wax can increase the effectiveness of the wax. Carbon GripSpray Base green is best suited for this.

Carbon GripSpray Klister

1) Buff any chipped areas



Thoroughly buff any chipped areas using sandpaper and remove dust using Base Tex.

2) Apply Carbon GripSpray Base green and cork



Apply a thin layer of Carbon GripSpray green to chipped areas. Spray on one half first, followed by the other half. Then apply Plasto Kork. **Important:** Keep GripSpray as upright as possible when spraying!



Leave Carbon GripSpray Base green to dry on the base for at least 5 minutes. For best results, leave Base green to dry overnight.

3) Apply Carbon GripSpray Klister and cork



Depending on the snow temperature and consistency, apply a thin layer of Carbon GripSpray Klister to chipped areas. Spray on one half first, followed by the other half. Then apply Plasto Kork. **Important:** Keep GripSpray as upright as possible when spraying!



Leave Carbon GripSpray Klister to dry on the base for at least